# Paramont Series

Adding a DVR/NVR to your Phone/Tablet using the NAT without registering an account (QR CODE no port forwarding needed)

This guide will be utilizing the web GUI, the only difference between here and the local monitor will be accessing the settings (ON LOCAL MONITOR TO ACCESS SETTINGS GO TO CIRCLE WITH FOUR SQUARES IN BOTTOM LEFT, THIS IS YOUR START BUTTON, CLICK SETTINGS, THIS WILL GIVE YOU SAME OPTIONS AS FUNCTION PANEL IN THIS GUIDE)

1. Access Function Panel

2. Click Network

3. Input your network Settings (it is recommended to leave the IPv4 on obtain automatically, that way if router is changed out at anytime service should not be interrupted as long as LAN Cable is plugged in, we also recommend using Googles DNS, and this guide will reflect that)

4. Click NAT (on Local Monitor this will be in the top bar above Ethernet Port 1)

5. Enable The NAT

6. Download the Paramont CMS App from either the App Store or Google Play Store

7. Open Paramont CMS Application & go to Menu Bars & Server List

8. Click Plus Sign in Upper Right Corner & select Scan Code to Add

9. Scan QR Code from NAT Screen on Recorder.

10. Input Password of Recorder

Server List(7/9)

DeviceName6
Type:Unknown Device Type

DeviceName5
Type:PD2B-8X

DeviceName3
Type:PN1A-16X16F

DeviceName4
Type:88720

DeviceName2
Type:PD2A-16

Click Play button to view Camera

Local device list only (can be backed up to cloud after creating account)

11. View Cameras

Modify Device

NEAFE029KD55

DeviceName2 ← *Name Device example "Home Cams"*

admin

← *Input password to your recorder. Default is 123456 unless it was changed*

Save